

FS 410 D

Spare Parts

Piezas de repuesto

Pieces de rechange

Ersatzteile

Reserveonderdelen

Ricambi

Peças sobresselente

Reservdelar


FS 410 D

PART NO.	POS.	DESCRIPTION	PART NO.	POS.	DESCRIPTION
501 97 95-02	A	Plate, Engine Mount	542 20 20-78	J1	Pointer, Single - compl
501 97 96-02	A	Bracket, Back Axle - Husq	542 20 20-93	M	Tank, Water
502 24 01-02	E	Decal, Control Panel, FS410D	542 20 20-99	D	Nut, Clip, M8 X 1.25
502 44 30-01	E	Cable, Throttle - Yanmar	542 20 21-06	A,J1,J2	Washer, Snub
502 44 79-02	H	Guard, Belt - Husq Gray	542 20 21-06	A,J1,J2	Washer Snub, Plated
502 46 72-02	H	Plate, Belt Guard - Husq Gray	542 20 21-13	G	Cable Assy
502 47 08-02	H	Spacer, Pulley, Yanmar - B/O	542 20 21-16	G	Spacer
502 49 75-01	H	Oil Drain - compl	542 20 21-28	L	Clip, Nose Piece
502 57 49-01	H	Engine, Yanmar	542 20 21-30	J1	Bar, Bent Finished
502 57 49-02	H	Bolt, Shaft, Engine, Yanmar	542 20 21-31	J1	Bar, Straight Finished
502 57 49-03	H	Key, Shaft, Engine, Yanmar	542 20 21-63	E	Wheel Depth Gauge
502 57 49-04	H	Washer, Sealing, Engine, Yanmar	542 20 21-64	E	Bracket Depth Gauge, Zinc Plated
502 85 62-05	E	Bracket, Console Bearing	542 20 21-65	G	Spring, Lifting
504 01 08-02	H	Grommet, Rubber, 5mm ID	542 20 21-66	G	Bracket, Spring Adjust, Pltd
504 03 12-07	E	Handle	542 20 21-69	E	Cap Round Vinyl
504 03 12-09	E	Handle w/ Grips	542 20 21-71	D	Plate Rivet, Plated
504 20 75-01	G	Raise/Lower Handle	542 20 21-84	I,K1,K2	Washer Tube 8mm ID
504 56 97-01	D	Decal, FS 410 D	542 20 21-85	I	Bar Tank Pivot
504 57 33-01	E,H	Meter, Hour/Tach - Rot. Shaft	542 20 21-86	I	Bar Lifting Bail
504 57 33-02	H	Magmet, Hour/Tach	542 20 21-87	I	U-Bolt
504 57 33-03	H	Nut, Hour/Tach	542 20 21-88	I	Washer Tube 12mm ID
504 57 52-02	E	Bracket, Tach - Console	542 20 22-16	G	Grease Zerk, M8 x 1.0, 90 Deg.
504 57 52-04	H	Bracket, Tach Sensor	542 20 22-52	I	Cage, Engine - Right
504 73 65-07	H	Pulley, PK, 67mm - 25.4mm, 12Gr B/O	542 20 22-55	I	Cage, Engine - Left
539 30 00-92	G	Key, Woodruff (ANSI #405)	542 20 22-70	J2	Pointer, Dual - compl
539 99 02-58	G	Nut, Hex 1/2"-13	542 20 22-71	J2	Bar, Outside - Dual Pointer
541 20 71-61	G	Handle Assembly	542 20 22-74	J2	Bar, Inside - Dual Pointer
541 20 71-76	G	Hand Crank Assembly	542 20 22-83	G	Spring, Extension
541 20 71-88	B	Slinger	542 20 22-89	A	Stud, M10-1.5 x 52mm
541 20 72-40	B	Tube, Bladeshaft	542 20 22-92	B	Wrench, 27mm Open
541 20 72-41	A,B	Bladeshaft - compl	542 20 23-00	G	Capscrew, Hex Hd M12-1.75x190 8.8 DIN 933
541 20 81-60	B	Bearing, Ball 62052-RS-C3	542 20 23-07	D	Pad, Resilient
541 20 81-90	H	Plate Tensioner Black	542 20 23-08	M	Fitting, Hose Swvl 3/4" FGH x 1/2" NPTM
541 20 81-94	H	Spacer Idler Sheave	542 20 23-11	L,M	Bracket, Hose Support
541 20 81-95	H	Sheave Idler	542 20 23-15	M	Water Side - compl
541 20 81-96	H	Idler Sheave -compl	542 20 23-20	M	Tank - Fitting Assy
541 20 82-30	N	Bearing 8mm	542 20 23-21	M	Fitting, 1/2" NPTM x 12mm Barb
541 20 82-45	N	Plate Spade Retaining Finished	542 20 23-34	E	Pin, Locking Z/P
541 20 82-46	N	Cover Blade Shaft Finished	542 20 23-38	G	Collar, Screw
541 20 82-49	N	Blade Guard Pivot Tube Plated	542 20 23-40	M	Fitting Adapter, 3/8" NPTM x 1/2" NPTF
541 20 82-63	N	Fitting 1/4 BSP x 6mm Barb 90deg	542 20 23-42	E	Console - Husq
541 20 82-78	D	Hinge Rubber	542 20 23-47	D	Cover Console - Husq
541 20 82-79	E	Shoulder Bolt M10 x 30	542 20 23-48	D	Side, Right - Husq Orange
541 20 82-81	D	Latch, 1/4 Turn	542 20 23-49	D	Side, Left - Husq Orange
541 20 82-84	L,M	Cap, Water	542 20 23-50	D	Door, Toolbox - Husq Orange
541 20 82-86	L,M	Tank, Water - compl	542 20 23-51	D	Cover, Toolbox - Husq Orange
542 04 56-40	M	Washer-Filter	542 20 23-52	D	Bottom, Toolbox - Husq Orange
542 13 92-73	C,H	Bearing, Ball 6204-2RS-C3	542 20 23-67	G	Nut Tube - Husq
542 13 95-37	M	Valve, Water 1/2" FPT	542 20 23-74	A	Shaft Guard - Husq
542 13 95-68	E	Grip, Handle	542 20 23-79	G	Insert, Bushing
542 13 97-68	H	Set Screw, Soc hd, M8-1.25 x 6 DIN 916	542 20 23-94	A	Bracket, Brake - Husq Orange
542 16 11-97	A	Isolator, 40-45 Durometer	542 20 23-96	A	Spring, Brake Z/P
542 16 12-35	D	Decal, PATENT PENDING	542 20 23-97	A	Pin, Brake Handle - Z/P
542 16 27-61	K1,K2	Clamp, Cord	542 20 23-99	A	Brake - compl
542 16 66-24	L	Fastener, Tufflock	542 20 24-07	A	Frame - Husq
542 16 71-85	B	Collar, Inner, 4.50"	542 20 24-16	C	Axle, Front Z/P
542 16 72-98	N	Decal, Warning, Blade Guard	542 20 24-17	C	Axle, Back Z/P
542 16 78-46	B	Nut, Bladeshaft 5/8-11 L.H.	542 20 24-20	C	Weldment, Axle - Husq Orange
542 16 78-47	B	Nut, Bladeshaft 5/8-11 R.H.	542 20 24-22	C	Lower Framing, Husq Orange - compl
542 16 79-62	B	Outer Collar W/ Pin - 4.50" OD	542 20 40-63	N	Spray Jet
542 16 79-64	B	Pin, Drive 3/8" OD x 1-1/8"	542 20 40-64	N	Splash Flap
542 16 90-65	H	Decal, Hot Muffler	542 20 40-89	N	Blade Guard - compl 20" [500mm]
542 17 21-37	K1,K2	Rope, Nylon 4mm Dia	542 20 40-96	N	Guard, Rear, Steel - 20" [500mm]
542 17 79-15	G	Screw, 5/8-8 Acme Thread B/O	542 20 40-97	N	Guard, Front, Steel - 20" [500mm]
542 18 44-55	A	Capscrew, Hex Hd M10-1.5x130 8.8 DIN 931	542 20 41-01	N	Tube, 10mm ODX2mm Wall - 20"
542 19 04-34	G	Bearing, Flange	542 20 41-13	E	Spring, Conical
542 19 05-88	E	Decal, Depth Gauge	542 20 41-44	N	Blade Guard, Rear - compl -20" [500mm]
542 19 05-93	D	Decal, Toolbox Warning	542 20 41-45	N	Blade Guard, Front - compl -20" [500mm]
542 19 06-17	L	Decal, Water Tank	542 20 41-49	L	Nose Piece - Husqvarna
542 19 06-38	E	Decal, Warning, Control Panel	542 20 41-85	A	Spade, Blade Guard - Husq
542 19 06-46	D	Decal, Local Service	543 04 49-63	H	Belt, PK Section, 12Gr x 841mm
542 19 07-33	E	Decal, HUSQVARNA	543 04 55-39	M	Valve, 1/2" BSP
542 19 61-83	M	O-ring, -210 NPR	543 04 55-80	M	Hose, Wate 12mm ID x 18mm OD (Per M)
542 19 61-84	M	Fitting, Water Tank	543 04 56-10	M	Quick Coupler, Male
542 20 20-62	C	Washer Plated	543 04 56-12	M	Quick Coupler, Female
542 20 20-75	J1,J2	Bushing, Spanner	543 04 57-88	D	Decal, Sound Level 108 dB(A)
542 20 20-77	J2	Rod, Threaded M10	543 04 58-91	D	Wrench 13mm


FS 410 D

PART NO.	POS.	DESCRIPTION	PART NO.	POS.	DESCRIPTION
543 04 59-32	J1,J2	Wheel, Pointer			
543 04 59-49	C	Wheel, Front, 125mm			
543 04 59-51	C	Wheel, Back, 200mm			
543 04 60-31	G	Plug, 1.25" OD			
543 85 01-31	M	Fitting, 1/4" Male x 12mm Barb, 90°			
543 85 03-44	M	Clip, Hose			
543 85 03-59	M	Quick Coupler, Male			
721 61 43-01	A,E	Pin, Cotter 1.6x22 ISO1234 DIN 94			
722 78 18-03	D	Pop Rivet, 3.2 Dia x 6.7mm Alum			
722 79 44-02	D	Pop Rivet, 4.0 Dia x 12.1mm Alum			
724 13 29-51	E,N	Machine Screw, Pan Hd M5-0.8x16 Z/P			
725 22 91-71	E	Capscrew, Hex Hd M4-0.7x12 8.8 DIN 933			
725 22 95-71	M	Capscrew, Hex Hd M4-0.7x20 8.8 DIN 933			
725 23 31-71	N	Capscrew, Hex Hd M5-0.8x20 8.8 DIN 933			
725 23 70-71	E,G	Capscrew, Hex Hd M6-1.0x20 8.8 DIN 933			
725 23 76-71	N	Capscrew, Hex Hd M6-1.0x35 8.8 DIN 933			
725 23 79-51	G	Capscrew, Hex Hd M6-1.0x45 8.8 DIN 931			
725 24 47-71	G,N	Capscrew, Hex Hd M8-1.25x12 8.8 DIN 933			
725 24 53-71	A,H	Capscrew, Hex Hd M8-1.25x25 8.8 DIN 933			
725 24 55-71	D,H,J1,J2	Capscrew, Hex Hd M8-1.25x30 8.8 DIN 933			
725 24 57-71	D,E	Capscrew, Hex Hd M8-1.25x35 8.8 DIN 933			
725 24 61-71	I	Capscrew, Hex Hd,M8-1.25x50 8.8 DIN 933			
725 24 63-51	I,K1,K2	Capscrew, Hex Hd M8-1.25x60 8.8 DIN 931			
725 24 71-51	N	Capscrew, Hex Hd M8-1.25x100 8.8 DIN 931			
725 24 71-71	A	Capscrew, Hex Hd M8-1.25x100 8.8 DIN 933			
725 24 73-51	H	Capscrew, Hex Hd M8-1.25x110 8.8 DIN 931			
725 24 93-71	C	Capscrew, Hex Hd M10-1.5x25 8.8 DIN 933			
725 25 01-51	H	Capscrew, Hex Hd M10-1.5x50 8.8 DIN 931			
725 25 03-51	G	Capscrew, Hex Hd M10-1.5x60 8.8 DIN 931			
725 25 05-51	A	Capscrew, Hex Hd M10-1.5x70 8.8 DIN 931			
725 25 15-71	J1	Capscrew, Hex Hd M10-1.5x120 8.8 DIN 933			
725 25 42-51	H	Capscrew, Hex Hd M12-1.75x50 8.8 DIN 931			
731 23 18-01	J1,J2	Nut, Hex M8-1.25, PC8 DIN 934			
731 23 20-01	J1,J2	Nut, Hex, M10-1.5 8.8 Din 934			
731 23 22-01	I	Nut, Hex M12-1.75, PC8 DIN 934			
732 25 12-01	M	Nut, Hex M4-0.7, Locking PC8 DIN 985			
732 25 14-01	N	Nut, Hex M5-0.8, Locking PC8 DIN 985			
732 25 16-01	G,N	Nut, Hex M6-1.0, Locking PC8 DIN 985			
732 25 18-01	D,E,I,J1,J2	Nut, Hex M8-1.25, Locking PC8 DIN 985			
732 25 18-01	J1-2,K1-2,N	Nut, Hex M8-1.25, Locking PC8 DIN 985			
732 25 20-01	A,G,H	Nut, Hex M10-1.50, Locking PC8 DIN 985			
732 25 22-01	I	Nut, Hex M12-1.75, Locking PC8 DIN 985			
734 11 52-01	E,G,N	Washer, Flat M6 DIN 125			
734 11 63-01	A,D,E,H,	Washer, Flat M8 DIN 125			
734 11 63-01	J2,K1,K2	Washer, Flat M8 DIN 125	504 59 19-01	N/S	OM Oper Man: FS 410D, 3L
734 11 65-41	H	Washer, Flat M8 Large	504 59 19-02	N/S	OM Oper Man: FS 410D, 5L
734 11 72-01	H	Washer, Flat M10 DIN 125	504 59 21-01	N/S	IPL Parts List: FS 410D
734 11 74-41	C	Washer, Flat M10 ISO 7093-10-140HV			
734 11 78-01	G	Washer, Flat M12 DIN 125	542 20 11-23	M	Inst. Sheet: Water Tank
734 11 80-41	H	Washer, Flat M12 ISO 7093-10-140HV			
735 11 36-01	E	Washer, Split M4 DIN 127	504 00 79-01	B	Kit, Blade Shaft Service (Heat Fit)
735 11 53-01	E	Washer, Split M6 DIN 127			
735 11 64-01	A,D,E,H,I	Washer, Split M8 DIN127			
735 11 73-01	A,C	Washer, Split M10 DIN127			
735 11 78-01	H	Washer, Split M12 DIN 127			
735 31 40-10	H	Snap Ring 47 x 1.75			

A Frame - FS 410 D




08.09.076




B Bladeshaft

* Compl. 541 20 72-41




08.09.07




C Lower Framing


542 20 24-22 Compl




11.06.06



D Toolbox



08.07.07



For local service, please contact your local Husqvarna Construction Products representative.

Para efectuar un servicio local, póngase en contacto con su representante local de Husqvarna Construction Products.

Pour toute réparation, contacter le représentant local de Husqvarna Construction Products.

Für Service vor Ort wenden Sie sich bitte an Ihren örtlichen Vertreter von Husqvarna Construction Products.

Neem voor plaatselijke service contact op met uw plaatselijke vertegenwoordiger van de constructieproducten van Husqvarna.

Per assistenza, rivolgersi al rappresentante di zona della Husqvarna Construction Products.

För service på platsen, kontakta din lokala representant för Husqvarna Construction Products.

Para obter serviço técnico local, contactar o representante da Husqvarna Construction Products local.

Europa / Europe:
Husqvarna
Construction Products
SE-433 81 Partille, Sweden
Tel: +46 31 94 90 00
Fax: +46 31 94 90 50

Asia Pacific:
Husqvarna
Construction Products,
Australia Pty Ltd
25-31 Kirkland Avenue
North Plympton, Adelaide,
South Australia 5037
Tel: +61 (0)8 8375 1000
Fax: +61 (0)8 8371 0990

The Americas:
Husqvarna Construction Products,
North America
17400 West 118th Street,
Olathe, Kansas 66061 USA
Toll-Free Telephone: 800-288-5040,
Telephone: 913-428-1300
Fax: 913-438-7938

— 542 19 06-46




— 543 04 57-88

PATENT PENDING


— 542 16 12-35

FS 410 D — 504 56 97-01


542 19 05-93




E Control Console



08.08.07



542 19 05-88



502 24 01-02

542 19 06-38

542 19 07-33

Husqvarna



G Screw Feed



08.08.07


Depth Gauge Spring & Cable

See Diag E





Screw Handle

541 20 71-61





H Engine & Idler - Diesel




541 20 81-96 Idler - Compl


05.08.07




Engine Cage - FS410D



08.09.07





J1 Pointer - ** Single **




08.09.07

*542 20 20-78 Compl




K1 Pointer Attachment ** Single Pointer **





11.06.06



See Diag I




J2 Pointer - ** Dual **




K2 Pointer Attachment ** Dual Pointer **



L Water Tank & Nose Piece




08.09.07




M Water System - FS410D

* 541 20 82-86 Water Tank - Compl (Optional)



08.09.07




N


Blade Guard - 20" [500mm]

542 20 40-89 Compl

**542 20 41-44 Rear Guard Compl




08.07.07



(NSS) - Not Sold Separately

542 16 72-98



Husqvarna Construction Products N. A.
Corporate Office
17400 West 119th Street
Olathe, Kansas 66061
Tel. 913-928-1000
Fax 913-438-7951

Customer Service: 800-288-5040
Customer Serv. Fax: 800-825-0028



DUST WARNING



Cutting, especially when DRY cutting, generates dust that comes from the material being cut, which frequently contains silica. Silica is a basic component of sand, quartz, brick clay, granite and numerous other minerals and rocks. Exposure to excessive amount of such dust can cause:

- Respiratory diseases (affecting your ability to breath), including chronic bronchitis, silicosis and pulmonary fibrosis from exposure to silica. These diseases may be fatal;
- Skin irritation and rash; and
- Cancer according to NTP* and IARC*
* National Toxicology Program / International Agency for Research on Cancer

Take precautionary steps

- Avoid inhalation of and skin contact with dust, mist and fumes;
- Wet cut when feasible, to minimize dust;
- Wear and ensure that all bystanders wear appropriate respiratory protection such as dust masks designed to filter out microscopic particles. (See OSHA 29 CFR Part 1910.1200)

California Prop 65 Warning:

Use of this product can cause exposure to materials known to the State of California to cause cancer and/or birth defects or other reproductive harm.



Printed in the USA