


K1260 K1260 RAIL

Reservdelar
Spare parts
Ersatzteile
Pieces de rechange
Piezas de repuesto
Ricambi
Peças sobresselente

No.	Pos.	Description	No.	Pos.	Description
506 27 92-06	A	BELT GUARD	503 23 51-09	EK	SPARK PLUG
501 26 97-04	D	VIB.INSULATOR	503 25 00-02	DF	BALL BEARING
501 26 97-04	G	ANTIVIBRATION ELEMENT	503 25 21-01	AR	BALL BEARING
501 27 08-01	D	GUIDE BUSHING	503 25 38-01	C	NEEDLE BEARING
501 35 43-01	R	CLIP	503 26 02-05	DEMP	SEALING RING
501 46 75-01	N	GASKET-METERING DIAP	503 26 60-03	GQ	COUPLER
501 46 84-01	N	SPRING-CHOKE FRICT.	503 26 60-04	GQ	COUPLER
501 46 85-01	N	BALL-CHOKE FRICTION	503 28 12-70	MN	CARBURETTOR
501 48 54-02	K	SPARK PLUG CAP	503 28 90-26	E	PISTON RING
501 63 48-01	K	SPRING	503 52 58-01	N	VALVE CHOKE
501 66 61-01	N	SCREEN-INLET	503 52 59-01	N	SPRING THROTT RETURN
501 67 32-03	K	PAWL	503 52 60-01	N	PIN THROTTLE STOP
501 69 28-01	N	COVER-METERING DIAPH	503 56 34-01	N	VALVE INLET NEEDLE
501 76 83-04	H	FUEL HOSE	503 56 45-01	N	SEAL-THROTTLE SHAFT
501 81 47-01	H	ANTIVIBRATIONS ELEME	503 57 42-01	N	PLUG-WELCH
501 81 57-01	D	BAR BOLT	503 57 76-02	H	FUEL HOSE
501 83 98-03	K	CABLE	503 57 89-01	H	HOLDER
501 89 41-03	E	PISTON CPL	503 59 55-01	N	O-RING
501 89 59-02	J	AIR CONDUCTOR	503 59 56-01	N	LEVER THROTTLE
501 89 59-03	J	AIR CONDUCTOR	503 59 57-01	N	LEVER THROTTLE INNER
501 89 67-01	J	STARTER PULLEY	503 59 58-01	N	COVER-PUMP
502 10 31-01	N	BUSHING-THROTT.SPR.	503 59 59-01	N	SHAFT ASS'Y THROTTLE
502 85 08-01	E	MUFFLER SUPPORT	503 59 65-01	N	SCREW
503 11 72-01	N	GASKET-PUMP	503 59 72-01	N	WASHER
503 11 73-01	N	DIAPHRAGM-PUMP	503 59 74-02	N	GASKET KIT
503 11 75-01	N	SCREW-PUMP COVER	503 59 84-01	N	FITTING FUEL INLET
503 12 79-01	J	STARTER HANDLE	503 63 24-01	N	VALVE THROTTLE
503 13 13-05	DEMP	GASKET MUFFLER	503 63 28-01	N	DIAPHRAGM ASSY METER
503 13 16-01	H	THROTTLE LOCKOUT	503 63 29-01	N	SCREW IDLE SPEED
503 13 18-01	H	SPRING	503 63 31-01	N	SPRING
503 13 20-01	D	GROMMET	503 63 32-01	N	NEEDLE IDLE SPEED
503 13 25-02	H	AV-ELEMENT	503 66 56-01	E	DECOMPRESSION VALVE
503 13 26-02	H	AV-ELEMENT	503 74 36-01	J	DISC
503 13 27-02	H	AV-ELEMENT	503 97 66-01	N	NOZZLE ASSY
503 13 29-01	EF	NEEDLE HOLDER	504 35 72-01	H	SINTER PLUG
503 13 36-01	H	THROTTLE LEVER	504 63 42-01	Q	NIPPLE
503 13 45-01	DEMP	CRANKCASE GASKET	504 63 44-01	Q	HOUSING
503 13 46-01	DEMP	GASKET	504 63 45-01	Q	HOUSING
503 13 50-01	J	RECOIL SPRING ASSY	504 63 46-01	Q	SCREW
503 14 08-01	H	BUSHING	504 90 94-65	M	SCREW
503 14 21-06	H	TANK UNIT ASSY	505 09 54-01	Q	HOSE KIT
503 14 23-01	H	THROTTLE CATCH	505 09 55-01	GQ	HOSE KIT
503 14 37-01	M	SEALING	505 10 35-01	Q	O-RING
503 14 49-01	C	CLUTCH ASSY	505 27 75-16	K	INSULATING CAP
503 14 51-01	C	CLUTCH SPRING	505 28 33-07	M	HOSE CLAMP
503 14 54-02	D	GROMMET	505 31 67-17	N	SCREW-LEVER PIN
503 19 22-01	N	SCREW PAN HD(M2.5x5)	505 31 67-31	N	PIN-METERING LEVER
503 20 00-45	A	SCREW COLLAR	505 31 67-34	N	LEVER-METERING
503 20 02-16	R	SCREW	505 31 67-37	N	SPRING-NEEDLE
503 20 72-05	A	SCREW	505 31 67-48	N	WASHER
503 21 06-16	J	SCREW	505 41 79-01	E	MUFFLER
503 21 28-06	K	SCREW	505 41 90-01	E	EXHAUST DUCT
503 21 45-16	H	SCREW	505 42 04-01	H	NUT
503 21 53-10	AGR	SCREW	505 52 42-01	Q	VALVE SPINDLE
503 21 53-12	DEGH	SCREW	505 57 41-16	AB	SCREW
503 21 53-20	BDKM	SCREW	506 00 69-01	K	SCREW
503 21 53-21	D	SCREW	506 02 83-01	N	WASHER
503 21 53-25	H	SCREW	506 02 87-01	B	FLANGE WASHER
503 21 53-26	JL	SCREW	506 02 88-30	B	BUSHING
503 21 53-30	L	SCREW	506 07 09-01	B	FLANGE WASHER
503 21 53-41	D	SCREW	506 13 95-11	ABR	WASHER
503 21 53-56	L	SCREW	506 13 96-01	ABR	COLLAR SCREW
503 21 53-65	D	SCREW	506 14 32-01	A	TORSION STOP
503 21 54-20	GQ	SCREW	506 22 75-01	R	SLEEVE
503 22 00-01	CD	NUT FLANGE	506 23 34-01	H	SUPPORT
503 22 10-03	K	NUT	506 23 70-01	D	AIR NOZZLE
503 23 00-05	E	WASHER	506 24 14-04	D	CUTTER ARM
503 23 00-42	K	WASHER STEEL	506 25 04-01	M	SUPPORT
503 23 01-04	A	WASHER	506 25 43-01	D	CHOKE CONTROL
503 23 43-02	J	WASHER	506 25 46-01	M	CHISEL GUIDE

No.	Pos.	Description	No.	Pos.	Description
506 25 58-02	J	STARTER COVER	525 32 18-01	L	COVER
506 25 59-03	H	TANK CAP ASSY	525 61 70-04	L	SEALING
506 26 41-01	H	FUEL FILTER	525 76 35-02	L	DECAL
506 26 41-11	H	FUEL FILTER	525 81 69-01	L	LABEL
506 26 63-02	B	LINING	525 81 69-02	L	LABEL
506 26 64-01	B	RATCHET FLANGE	525 81 81-03	L	DECAL
506 26 65-01	B	FLANGE	525 81 81-04	L	DECAL
506 26 68-01	A	COMPRESSION SPRING	525 82 04-01	G	GROUND SUPPORT
506 26 84-01	C	SPACING SLEEVE	530 03 50-15	N	SCREW-VALVE
506 27 11-01	H	HOSE CLAMP	535 03 94-01	R	CONNECTION PLATE
506 27 17-03	C	BELT GUARD	537 00 28-01	N	RING
506 27 43-02	DEMP	GASKET	537 00 29-01	N	COVER
506 27 52-02	M	INLET PIPE	537 00 30-01	N	SHAFT ASS'Y
506 27 55-04	J	STARTER	537 00 31-01	N	SCREW
506 27 92-07	A	BELT GUARD	537 15 34-01	N	JET
506 27 92-08	A	BELT GUARD	540 05 28-01	C	GEAR WHEEL ASSY
506 28 41 22	B	LABEL	540 05 28-03	C	GEAR WHEEL ASSY
506 28 41-12	B	LABEL	544 21 84-20	DEH	SCREW
506 28 41-14	B	LABEL	544 21 84-47	G	SCREW
506 28 41-24	B	LABEL	544 81 16-01	G	BASE
506 28 44-01	A	SCREW COLLAR	544 87 35-01	J	LABEL
506 28 59-01	C	SPACING SLEEVE	544 87 36-01	C	LABEL
506 28 73-01	A	NUT	544 87 38-01	L	LABEL
506 28 84-01	AR	SCREEN PATTERN FLANG	544 97 63-01	A	BELT
506 28 97-01	M	FLANGE	544 97 63-02	A	BELT
506 28 98-01	H	THROTTLE WIRE	544 98 50-01	A	PULLEY
506 29 21-01	H	GASKET	574 51 22-01	H	NUT LOCKING
506 29 24-03	DEMP	GASKET KIT	574 56 04-01	E	SCREW
506 29 39-01	H	TANK WENT	576 12 09-01	L	DECAL
506 29 57-02	Q	NIPPLE	576 12 10-02	B	LABEL
506 29 83-65	AR	SHAFT	576 12 10-03	B	LABEL
506 29 88-01	Q	FILTER	576 22 39-01	D	CRANKCASE
506 31 38-01	M	INSERT	576 22 40-01	S	SHORT BLOCK
506 31 86-02	K	STOP SWITCH	576 27 00-01	E	CYLINDER
506 32 48-01	B	SUPPORT FLANGE	576 55 32-01	L	CYLINDER COVER
506 33 56-25	J	STARTER CORD	576 66 57-01	R	BEARING HOUSING
506 33 56-50	J	STARTER CORD	576 66 57-02	R	BEARING HOUSING
506 34 05-44	B	WHEEL GUARD ASSY	576 66 57-03	R	BEARING HOUSING
506 34 05-46	B	WHEEL GUARD ASSY	576 66 57-04	R	BEARING HOUSING
506 34 05-54	B	WHEEL GUARD ASSY	576 76 90-01	N	SPRING-METER.LEVER
506 34 05-56	B	WHEEL GUARD ASSY	577 34 38-01	F	CRANKSHAFT ASSY
506 34 14-01	E	COOLING PLATE	720 12 40-20	H	PARALLEL PIN
506 34 46-02	B	HANDLE	720 12 78-06	H	PIN
506 35 27-01	Q	PROTECTIVE SPRING	721 42 06-00	D	PIN
506 35 80-01	R	BRACKET	724 12 87-59	R	SCREW
506 35 90-01	R	WIRING	729 52 91-71	R	SCREW
506 35 91-03	R	STOP SWITCH	732 25 12-01	R	NUT
506 35 91-04	R	STOP SWITCH	734 11 47-41	G	WASHER
506 35 96-01	R	SPACING BLOCK	735 11 73-50	K	SPRING WASHER
506 37 96-20	B	BUSHING	735 88 06-00	F	WOODRUFF KEY
506 37 96-22	B	BUSHING	737 44 13-00	E	CIRCLIP
506 37 96-25	B	BUSHING			
506 38 26-01	P	COMBINATION TOOL			
506 38 60-12	Q	VALVE ASSY			
506 38 78-34	K	IGNITION CABLE			
506 39 42-08	A	BEARING HOUSING			
506 40 93-01	A	NUT			
506 49 87-01	Q	HOSE CLAMP			
506 49 87-02	Q	HOSE CLAMP			
506 60 68-06	Q	HOSE			
506 60 75-01	Q	HOSE			
510 11 56-01	K	IGNITION MODULE			
510 24 37-01	M	INLET ELBOW			
510 24 38-01	M	BELLOWS			
510 24 39-01	M	FILTER CONNECTION			
510 24 41-03	L	AIR FILTER			
516 00 24-01	E	SCREW			
521 95 48-01	G	HANDLE			
522 89 20-04	K	FLYWHEEL ASSY			
525 32 16-01	L	FILTER COVER			



A K1260
K1260 Rail




Page A
K1260, K1260 Rail

Pos.	Part No.	Description	Quantity	Notes	New Part
1	506 27 92-06	BELT GUARD	1	Incl. 2 - 4	
1	506 27 92-07	BELT GUARD	1	Rail 14", Incl. 2 - 4	
1	506 27 92-08	BELT GUARD	1	Rail 16", Incl. 2 - 4	
2	506 40 93-01	NUT	1		
3	506 26 68-01	COMPRESSION SPRING	1		
4	503 20 72-05	SCREW	1		
5	506 28 44-01	SCREW COLLAR	2		
6	503 20 00-45	SCREW COLLAR	1		
7	503 23 01-04	WASHER	2		
8	544 97 63-01	BELT	1	14", 16", Rail 14"	
8	544 97 63-02	BELT	1	Rail 16"	
9	544 98 50-01	PULLEY	1		
10	506 39 42-08	BEARING HOUSING	1	Incl. 11 - 15	
11	505 57 41-16	SCREW	1		
12	506 14 32-01	TORSION STOP	1		
13	506 28 73-01	NUT	2		
14	503 21 53-10	SCREW	2		
15	506 28 84-01	SCREEN PATTERN FLANGE	1		
16	503 25 21-01	BALL BEARING	2		
17	506 29 83-65	SHAFT	1	Incl. 18 - 19	
18	506 13 95-11	WASHER	1		
19	506 13 96-01	COLLAR SCREW	1		

B K1260 K1260 Rail



13




14

Page B
K1260, K1260 Rail

Pos.	Part No.	Description	Quantity	Notes	New Part
1	506 34 05-44	WHEEL GUARD ASSY	1	14". Incl. 2 - 4	
1	506 34 05-46	WHEEL GUARD ASSY	1	16". Incl. 2 - 4	
1	506 34 05-54	WHEEL GUARD ASSY	1	14" Rail, Incl. 2 - 4	
1	506 34 05-56	WHEEL GUARD ASSY	1	16" Rail, Incl. 2 - 4	
2	506 26 63-02	LINING	1		
3	503 21 53-20	SCREW	1		
4	506 34 46-02	HANDLE	1		
5	506 26 64-01	RATCHET FLANGE	1		
6	506 26 65-01	FLANGE	1		
7	505 57 41-16	SCREW	3		
8	506 32 48-01	SUPPORT FLANGE	1		
9	506 02 87-01	FLANGE WASHER	1	Diam 105	
9	506 07 09-01	FLANGE WASHER	1	Diam 119	
10	506 37 96-20	BUSHING	1	Diam 20	
10	506 37 96-22	BUSHING	1	Diam 22,2	
10	506 37 96-25	BUSHING	1	Diam 25	
10	506 02 88-30	BUSHING	1	Diam 30,5	
11	506 13 96-01	COLLAR SCREW	1		
12	506 13 95-11	WASHER	1		
13	506 28 41-12	LABEL	1	14". Diam 20 mm	
13	506 28 41-14	LABEL	1	14". Diam 1"	
13	506 28 41 22	LABEL	1	16". Diam 20 mm	
13	506 28 41-24	LABEL	1	16". Diam 1"	
14	576 12 10-02	LABEL	1	Japan 14"	
14	576 12 10-03	LABEL	1	Japan 16"	



C K1260
K1260 Rail



Page C**K1260, K1260 Rail**

Pos.	Part No.	Description	Quantity	Notes	New Part
1	506 27 17-03	BELT GUARD	1	Incl. 2, 3	
2	544 87 36-01	LABEL	1		
3	506 26 84-01	SPACING SLEEVE	1		
4	503 22 00-01	NUT FLANGE	1		
5	503 14 49-01	CLUTCH ASSY	1	Incl. 6	
6	503 14 51-01	CLUTCH SPRING	3		
7	540 05 28-01	GEAR WHEEL ASSY	1	14". Incl. 8	
7	540 05 28-03	GEAR WHEEL ASSY	1	16". Incl. 8	
8	503 25 38-01	NEEDLE BEARING	1		
9	506 28 59-01	SPACING SLEEVE	1		


D K1260
K1260 Rail




Page D
K1260, K1260 Rail

Pos.	Part No.	Description	Quantity	Notes	New Part
1	576 22 39-01	CRANKCASE	1	Incl. 2-11	
2	503 13 45-01	CRANKCASE GASKET	1		
3	503 21 53-20	SCREW	1		
4	503 25 00-02	BALL BEARING	2		
5	503 21 53-41	SCREW	9		
6	501 27 08-01	GUIDE BUSHING	4		
7	503 21 53-21	SCREW	1		
8	503 21 53-65	SCREW	2		
9	501 81 57-01	BAR BOLT	2		
10	721 42 06-00	PIN	1		
11	503 26 02-05	SEALING RING	2		
12	506 25 43-01	CHOKE CONTROL	1		
13	503 14 54-02	GROMMET	1		
14	503 13 20-01	GROMMET	1		
15	501 26 97-04	VIB.INSULATOR	1		
16	544 21 84-20	SCREW	1		
17	503 22 00-01	NUT FLANGE	1		
18	506 24 14-04	CUTTER ARM	1		
19	506 23 70-01	AIR NOZZLE	1		
20	503 21 53-12	SCREW	1		
21	506 29 24-03	GASKET KIT	1	Incl. 2, 11, 22 - 24	
22	506 27 43-02	GASKET	1		
23	503 13 13-05	GASKET MUFFLER	1		
24	503 13 46-01	GASKET	1		

E K1260
K1260 Rail




19



Page E
K1260, K1260 Rail



Pos.	Part No.	Description	Quantity	Notes	New Part
1	503 66 56-01	DECOMPRESSION VALVE	1		
2	516 00 24-01	SCREW	4		
3	503 23 00-05	WASHER	4		
4	503 23 51-09	SPARK PLUG	1	RCJ 6Y	
5	576 27 00-02	CYLINDER	1	Incl. 6 - 8	
6	503 13 46-01	GASKET	1		
7	501 89 41-03	PISTON CPL	1	Incl. 9 - 10	
8	503 13 29-01	NEEDLE HOLDER	1		
9	503 28 90-26	PISTON RING	2		
10	737 44 13-00	CIRCLIP	2		
11	506 34 14-01	COOLING PLATE	1		
12	503 13 13-05	GASKET MUFFLER	1		
13	505 41 79-01	MUFFLER	1	Incl. 14 - 15	
14	574 56 04-01	SCREW	4		
15	505 41 90-01	EXHAUST DUCT	1		
16	544 21 84-20	SCREW	3		
17	503 21 53-12	SCREW	2		
18	502 85 08-01	MUFFLER SUPPORT	1		
19	506 29 24-03	GASKET KIT	1	Incl. 6, 12, 20 - 22	
20	506 27 43-02	GASKET	1		
21	503 13 45-01	CRANKCASE GASKET	1		
22	503 26 02-05	SEALING RING	2		

F K1260
K1260 Rail




Page F
K1260, K1260 Rail

Pos.	Part No.	Description	Quantity	Notes	New Part
1	577 34 38-01	CRANKSHAFT ASSY	1	Incl. 2, 3	
2	503 25 00-02	BALL BEARING	2		
3	503 13 29-01	NEEDLE HOLDER	1		
4	735 88 06-00	WOODRUFF KEY	1		




11



Page G**K1260, K1260 Rail**


Pos.	Part No.	Description	Quantity	Notes	New Part
1	503 21 53-10	SCREW	1		
2	503 21 54-20	SCREW	2		
3	521 95 48-01	HANDLE	1		
4	501 26 97-04	ANTIVIBRATION ELEMENT	1		
5	544 21 84-47	SCREW	2		
6	525 82 04-01	GROUND SUPPORT	1	Incl. 7 - 9	
7	544 81 16-01	BASE	2		
8	734 11 47-41	WASHER	2		
9	503 21 53-12	SCREW	3		
10	503 26 60-03	COUPLER	1	USA, Canada	
10	503 26 60-04	COUPLER	1		
11	505 09 55-01	HOSE KIT	1		



Page H
K1260, K1260 Rail

Pos.	Part No.	Description	Quantity	Notes	New Part
1	503 14 21-06	TANK UNIT ASSY	1	Incl. 1 - 15, 17	
2	506 28 98-01	THROTTLE WIRE	1		
3	503 14 08-01	BUSHING	1		
4	503 57 76-02	FUEL HOSE	1		
5	504 35 72-01	SINTER PLUG	1		
6	501 76 83-04	FUEL HOSE	1		
7	506 29 39-01	TANK WENT	1		
8	720 12 78-06	PIN	1		
9	720 12 40-20	PARALLEL PIN	1		
10	503 13 16-01	THROTTLE LOCKOUT	1		
11	503 13 18-01	SPRING	1		
12	503 13 36-01	THROTTLE LEVER	1		
13	503 14 23-01	THROTTLE CATCH	1		
14	506 23 34-01	SUPPORT	1		
15	503 21 45-16	SCREW	2		
16	503 13 26-02	AV-ELEMENT	1		
17	506 26 41-11	FUEL FILTER	1	Incl. 18 - 19	
18	506 27 11-01	HOSE CLAMP	1		
19	506 26 41-01	FUEL FILTER	1		
20	503 21 53-25	SCREW	2		
21	503 13 27-02	AV-ELEMENT	1		
22	503 13 25-02	AV-ELEMENT	1		
23	544 21 84-20	SCREW	2		
24	506 25 59-03	TANK CAP ASSY	1	Incl. 25 - 26	
25	506 29 21-01	GASKET	1		
26	503 57 89-01	HOLDER	1		
27	505 42 04-01	NUT	2		
28	501 81 47-01	ANTIVIBRATIONS ELEME	1		
29	503 21 53-12	SCREW	1		
30	574 51 22-01	NUT LOCKING	1		



J K1260
K1260 Rail



Page J**K1260, K1260 Rail**

Pos.	Part No.	Description	Quantity	Notes	New Part
1	506 27 55-04	STARTER	1	Incl. 2 - 11	
2	503 21 06-16	SCREW	1		
3	503 23 43-02	WASHER	1		
4	501 89 67-01	STARTER PULLEY	1		
5	506 33 56-25	STARTER CORD	1		
5	506 33 56-50	STARTER CORD	1	50 meter	
6	503 12 79-01	STARTER HANDLE	1		
7	503 74 36-01	DISC	1		
8	503 13 50-01	RECOIL SPRING ASSY	1		
9	506 25 58-02	STARTER COVER	1		
10	503 21 53-26	SCREW	4		
11	544 87 35-01	LABEL	1		
12	501 89 59-02	AIR CONDUCTOR	1		
12	501 89 59-03	AIR CONDUCTOR	1	Rail Stop Switch only	




K K1260
K1260 Rail



Page K
K1260, K1260 Rail

Pos.	Part No.	Description	Quantity	Notes	New Part
1	503 21 28-06	SCREW	1		
2	506 31 86-02	STOP SWITCH	1		
3	501 83 98-03	CABLE	1		
4	503 23 51-09	SPARK PLUG	1	RCJ 6Y	
5	501 48 54-02	SPARK PLUG CAP	1		
6	510 11 56-01	IGNITION MODULE	1	Incl. 7 - 8	
7	506 38 78-34	IGNITION CABLE	1		
8	505 27 75-16	INSULATING CAP	1		
9	503 21 53-20	SCREW	2		
10	735 11 73-50	SPRING WASHER	1		
11	503 22 10-03	NUT	1		
12	522 89 20-04	FLYWHEEL ASSY	1	Incl. 13 - 16	
13	501 63 48-01	SPRING	2		
14	503 23 00-42	WASHER STEEL	2		
15	501 67 32-03	PAWL	2		
16	506 00 69-01	SCREW	2		


L K1260 K1260 Rail




Page L**K1260, K1260 Rail**

Pos.	Part No.	Description	Quantity	Notes	New Part
1	503 21 53-56	SCREW	2		
2	503 21 53-26	SCREW	1		
3	525 76 35-02	DECAL	1		
5	525 81 81-03	DECAL	1	USA	
5	525 81 81-04	DECAL	1	Canada, CE	
5	576 12 09-01	DECAL	1	Japan	
4	525 32 18-01	COVER	1		
6	525 32 16-01	FILTER COVER	1		
7	510 24 41-03	AIR FILTER	1		
8	576 55 32-01	CYLINDER COVER	1	Incl. 9 - 10	
9	525 61 70-04	SEALING	2		
10	544 87 38-01	LABEL	1		
11	503 21 53-30	SCREW	5		
12	525 81 69-01	LABEL	1	K1260	
12	525 81 69-02	LABEL	1	K1260 Rail	

M K1260
K1260 Rail





15



Page M
K1260, K1260 Rail



Pos.	Part No.	Description	Quantity	Notes	New Part
1	510 24 39-01	FILTER CONNECTION	1		
2	510 24 38-01	BELLOWS			
3	505 28 33-07	HOSE CLAMP	1		
4	510 24 37-01	INLET ELBOW	1		
5	504 90 94-65	SCREW	2		
6	506 25 04-01	SUPPORT	1		
7	506 27 43-02	GASKET	1		
8	503 28 12-70	CARBURETTOR	1		
9	506 25 46-01	CHISEL GUIDE	1		
10	506 28 97-01	FLANGE	1		
11	503 21 53-20	SCREW	2		
12	506 27 52-02	INLET PIPE	1	Incl. 13 - 14	
13	503 14 37-01	SEALING	1		
14	506 31 38-01	INSERT	1		
15	506 29 24-03	GASKET KIT	1	Incl. 7, 16 - 19	
16	503 13 13-05	GASKET MUFFLER	1		
17	503 26 02-05	SEALING RING	2		
18	503 13 45-01	CRANKCASE GASKET	1		
19	503 13 46-01	GASKET	1		



Page N
K1260, K1260 Rail

Pos.	Part No.	Description	Quantity	Notes	New Part
1	503 28 12-70	CARBURETTOR	1	Walbro WG-9A	
2	537 00 31-01	SCREW	1		
3	501 69 28-01	COVER-METERING DIAPH	1		
4	537 00 29-01	COVER	1		
5	537 00 28-01	RING	1		
6	503 63 28-01	DIAPHRAGM ASSY METER	1	Kit 45	
7	501 46 75-01	GASKET-METERING DIAP	1	Kit 45	
8	505 31 67-31	PIN-METERING LEVER	1		
9	505 31 67-34	LEVER-METERING	1		
10	503 56 34-01	VALVE INLET NEEDLE	1		
11	576 76 90-01	SPRING-METER.LEVER	1		
12	537 15 34-01	JET	1		
13	501 46 85-01	BALL-CHOKE FRICTION	1		
14	501 46 84-01	SPRING-CHOKE FRICT.	1		
15	503 97 66-01	NOZZLE ASSY	1		
16	503 57 42-01	PLUG-WELCH	1		
17	503 59 55-01	O-RING	1		
18	503 59 72-01	WASHER	1		
19	505 31 67-37	SPRING-NEEDLE	1		
20	503 63 31-01	SPRING	1		
21	503 52 60-01	PIN THROTTLE STOP	1		
22	503 63 29-01	SCREW IDLE SPEED	1		
23	503 63 32-01	NEEDLE IDLE SPEED	1		
24	503 59 65-01	SCREW	1		
25	506 02 83-01	WASHER	1		
26	503 59 59-01	SHAFT ASS'Y THROTTLE	1		
27	505 31 67-17	SCREW-LEVER PIN	1		
28	537 00 30-01	SHAFT ASS'Y	1		
29	503 52 58-01	VALVE CHOKE	1		
30	530 03 50-15	SCREW-VALVE	2		
31	503 19 22-01	SCREW PAN HD(M2.5x5)	1		
32	503 59 56-01	LEVER THROTTLE	1		
33	502 10 31-01	BUSHING-THROTT.SPR.	2		
34	503 52 59-01	SPRING THROTT RETURN	1		
35	505 31 67-48	WASHER	2		
36	503 56 45-01	SEAL-THROTTLE SHAFT	2		
37	503 59 84-01	FITTING FUEL INLET	1		
38	503 63 24-01	VALVE THROTTLE	1		
39	501 66 61-01	SCREEN-INLET	1		
40	503 59 57-01	LEVER THROTTLE INNER	1		
41	503 11 73-01	DIAPHRAGM-PUMP	1	Kit 45	
42	503 11 72-01	GASKET-PUMP	1	Kit 45	
43	503 59 58-01	COVER-PUMP	1		
44	503 11 75-01	SCREW-PUMP COVER	1		
45	503 59 74-02	GASKET KIT	1		


P K1260
K1260 Rail
Accessories
Zubehöre
Accessoires
Accesorios
Tillbehör



Page P
K1260, K1260 Rail

Pos.	Part No.	Description	Quantity	Notes	New Part
1	506 38 26-01	COMBINATION TOOL	1	Torx 27	
2	506 29 24-03	GASKET KIT	1	Incl. 3 - 7	
3	506 27 43-02	GASKET	1		
4	503 13 13-05	GASKET MUFFLER	1		
5	503 26 02-05	SEALING RING	2		
6	503 13 45-01	CRANKCASE GASKET	1		
7	503 13 46-01	GASKET	1		


Q



Page Q**K1260, K1260 Rail**


Pos.	Part No.	Description	Quantity	Notes	New Part
1	505 09 55-01	HOSE KIT	1	Incl. 2, 5 - 7	
2	506 29 57-02	NIPPLE	1	Incl. 3, 4	
3	506 29 88-01	FILTER	1		
4	505 10 35-01	O-RING	1		
5	506 49 87-02	HOSE CLAMP	1		
6	506 60 75-01	HOSE	1		
7	506 38 60-12	VALVE ASSY	1	Incl. 8	
8	503 21 54-20	SCREW	2		
9	505 52 42-01	VALVE SPINDLE	1		
10	506 35 27-01	PROTECTIVE SPRING	1		
11	505 09 54-01	HOSE KIT	1		
12	506 49 87-01	HOSE CLAMP	4		
13	506 60 68-06	HOSE	1	620 mm	
14	504 63 46-01	SCREW	2		
15	504 63 44-01	HOUSING	1		
16	504 63 42-01	NIPPLE	2		
17	504 63 45-01	HOUSING	1		
18	503 26 60-03	COUPLER	1	USA, Canada	
18	503 26 60-04	COUPLER	1		

R K1260
K1260 Rail



Page R
K1260 Rail

Pos.	Part No.	Description	Quantity	Notes	New Part
1	576 66 57-02	BEARING HOUSING	1	14" Rail Stop Switch, Incl. 2 - 11	
2	506 35 91-04	STOP SWITCH	1	RH	
3	506 35 91-03	STOP SWITCH	1	LH	
4	729 52 91-71	SCREW	2		
5	506 35 96-01	SPACING BLOCK	1		
6	501 35 43-01	CLIP	1		
7	506 35 90-01	WIRING	1		
8	732 25 12-01	NUT	1		
9	724 12 87-59	SCREW	1		
10	506 35 80-01	BRACKET	1		
11	576 66 57-01	BEARING HOUSING	1	14" Rail, Incl. 12 - 17	
11	576 66 57-03	BEARING HOUSING	1	16" Rail, Incl. 12 - 17	
11	576 66 57-04	BEARING HOUSING	1	16" Rail USA, Incl. 12 - 17	
12	506 22 75-01	SLEEVE	2		
13	503 20 02-16	SCREW	2		
14	506 28 84-01	SCREEN PATTERN FLANG	1		
15	503 25 21-01	BALL BEARING	2		
16	503 21 53-10	SCREW	2		
17	506 29 83-65	SHAFT	1	Incl. 18 - 19	
18	506 13 95-11	WASHER	1		
19	506 13 96-01	COLLAR SCREW	1		
20	535 03 94-01	CONNECTION PLATE	1		



Page S K1260, K1260 Rail					
Pos.	Part No.	Description	Quantity	Notes	New Part
1	576 22 40-01	SHORT BLOCK	1		